

# **Ezi-SERVO<sup>®</sup> Plus-R**

Closed Loop Stepping System  
with Network based Motion Controller

## User Manual

Position Table



[www.fastech.co.kr](http://www.fastech.co.kr)

## - Table of Contents -

1. Before Getting Started_____	3
2. Window of Position Table(PT)_____	3
2.1 Opening_____	3
2.2 Main Window of Position Table_____	4
2.3 Position Table Editor_____	5
3. Position Table(PT) Items_____	6
3.1 Description of Position Table Items_____	6
3.2 Command Items_____	6
4. Executing Position Table(PT)_____	9
4.1 Starting Position Table_____	9
4.2 General Operation Examples_____	9
4.3 Operation Modes_____	10
4.3.1 Normal_____	10
4.3.2 Single Step_____	10
4.4 Teaching Function_____	11
4.4.1 Teaching by User Program_____	11
4.4.2 Teaching by Input Signals_____	12
4.5 Input Condition Jump Function_____	13
4.5.1 Automatic Jump_____	13
4.5.2 Jump by External Signals_____	14
4.6 Loop Condition Jump Function_____	15
4.6.1 Setting the Loop_____	15
4.6.2 Clearing Loop Counter_____	16
4.7 Start/Stop Signal Function _____	17

# 1. Before Getting Started

The present Products 「Ezi-SERVO Plus-R User Manual “Position Table”」 explains position table functions of Ezi-SERVO Plus-R. Here is 「[User Manual\\_Text](#)」, 「[User Manual\\_Communication Function](#)」 with the present manual. Please utilize our product afterward understanding about proper usage method with reading these contents carefully. The word as ‘Position Table’ can be presented as PT ( Position Table ) from the following text.


In particular, Please don’ t forget to memorize whole matters that requires attention about safety in 「User Manual\_Text」 and should try to understand properly. Besides please be safe to do not use the products improperly in any case. At worst, serious concern can be occurred as like death.

We provide this instruction manual and other instruction manual as well. Please keep these manuals in appropriate place whenever you need to find and read comfortably.

## 2. Windows of Position Table

### 2.1. Loading Position Table Data

When click the ‘Pos Table’ button on main menu of User Program(GUI), then the system displays the following message box and loads data saved in RAM area of drive.



Functions of Position Table allows to process motions in the orders that were predefined by user. In the case of this Ezi-SERVO PlusR drive, up to 256 steps can be saved.


Major functions for saving items are shown as following:


- (1) Editing function of Motion step (Input/Edit/Delete/Copy)
- (2) Start and Stop function of Motion order at User Program(GUI)
- (3) Start and Stop Motion function of by signal input from outside drive.
- (4) Teaching function
- (5) Functions to save Motion steps as file and to load them from file
- (6) View function of current Position Table order under execution

When electric power is supplied to drive, the Position Table data saved in ROM area in drive is copied to RAM area and once click the ‘Post Table’ button, then the system loads the data saved in RAM area of drive.

## 2.2 Main Window of Position Table

The following window describes windows and buttons which execute the position table function.



Button	Description
Normal/Single Step	The user can select modes to execute the position table. Normal : All position commands are in order executed according to conditions saved in the position table. Single Step : Only single position command is executed.
Run/Stop/Next	To run/stop items at the defined position table
Teaching	Teaching is executed by either using external input signal or user program. By clicking this button, the user can easily use teaching function at the user program window. For more information, refer to 'Teaching Function' .
Refresh	To display the position value measured by the teaching function. For more information, refer to 'Teaching Function' .
Save to ROM	To save current position table data in ROM drive.
Load from ROM	To open position table data saved in ROM drive
Save to file	To save current position table data to an external file (It is saved to a folder defined by the user with a file name defined by the user. The extension is *.txt.)
Load File	To read position table data saved to external file 

- \* Up to 256 position table commands can be input and saved.
- \* By using each position table command, the user can edit the file such as edit, copy, paste, and delete.

## 2.3. Position Table Editor

When click right mouse button on a selected Position Table data line, then the following popup menu is activated.

Position Table					
No.	CMD	Position	Low Spd	High Spd	Accel
0	3	5555	1	10000	100
1	3	0	1	10000	100
2	3	25000	1	50000	100
3	3	0	1	50000	100
4	3	25000	1	50000	100
5					100
6					100
7					100
8					100
9					100
10					100
11					100
12					100
13					100
14					100
15					100
16					100
17					100

- (1) Edit Item: You can edit data on the following dialog box shown below.
- (2) Clear Item: All the items of selected PT are cleared.  
After executing this function all the items are shown as blank.
- (3) Clear All Items: While above function "Clear Item" clears data for one selected order, this function clears data for all the orders of 256 Position Table.
- (4) Reload Item from ROM: The data shown on the screen are values saved in the RAM.  
This function is used for reload data saved in ROM area.
- (5) Cut Item: Used to cut selected item data of PT in order to paste on other position.
- (6) Copy Item: Used to copy selected item data of PT in order to paste on other position.
- (7) Paste Item: Right the copied data to clipboard by "Cut" or "Copy" to other selected position.
- (8) Run Selected Item: Execute motion order from the selected no of Position Table.

Double click on selected line of Position Table data or click the "Edit Item" popup menu button shown above figure, then the dialog box shown right is activated.

Once complete editing of each item, and then you move and select other items to edit by using right/left arrow key.

After complete editing of all data, click 'Save' button to save data to RAM.  
In order to save data to ROM area, click 'Save to ROM' button on main screen of Position Table.

**Position Table Item Editor**

Item No. : 0010

Command: ABS - Normal Motion

**Motion**

Position: 17500

Low Speed: 1

High Speed: 100000

Accel Time: 100

Decel Time: 100

Check Inposition

Enable Continuous Action

Waiting Time after command: 100

Clear Loop Count

JP Table No.: [ ]

**Jump**

JP Table No.: 11

JPT 0

JPT 1

JPT 2

Counting Loop

Loop Count: 0

JP Table No. at the end of loop: [ ]

PT Output Set

Start Sign  End Sign

PT 0  PT 1  PT 2

Buttons: Begin, End, Save, Close


### 3. Position Table Item

#### 3.1 Explanation of Position Table Item

Designated Item	Description	Unit	Lower limit	Upper limit
Command	Specifies type of motion. For more details, refer to 「3.2 Command」.	-	0	9
Position	Specifies position/movement scale by number of pulse.	pulse	-134,217,728	+134,217,727
Low Speed	Specifies low speed by number of pulse in accordance with type of motion. For more details, refer to 「3.2 Command」.	pps	0	500,000
High Speed	Specifies high speed by number of pulse in accordance with type of motion. For more details, refer to 「3.2 Command」.	pps	0	500,000
ACC time	Specified acceleration time by msec when starting motion.	ms	1	9,999
DEC time	Specified acceleration time by msec when stopping motion.	ms	1	9,999
Wait time	Specifies waiting time by msec for starting motion of next PT when specifying PT no for jump/skip. If JP Table No is specified as blank or 'Continuous Action' is specified, this is ignored.	ms	0	60,000
<p>Note) Even if Wait Time is specified as 0[ms], the system waits for the completion signal of position setting (INP signal) or motor stop signal before starting next Position Table</p>				
Continuous action	If this item is checked as 'check (1)', the system continues actions of current position and next position.	-	0	1

Example) When Position No 0, 1 are specified as under, that is, position 0 is specified as Continuous Action,

PT No	Cont Act	JPT No
Position 0	1	1
Position 1	0	-







<b>JP Table No.</b>	When this item specified, the system jumps to JP Table No and execute it after completing action of current position. If Position No is specified as 10XXX, system jumps to Position No XXX as soon as 'JPT Start', one of the input digital signal to controller from outside, becomes ON. For program exit, specify as blank. For more details, refer to 「4.4 Input Condition - Jump」.	-	0	255								
			10,000	10,255								
<b>JPT 0</b>	If any of these items is checked and there are corresponding input signals of JPT input0, JPT input1 or JPT input2, system jumps to JPT 0, JPT 1 or JPT 2 accordingly regardless of specified 'Jump Table No.'. For more details, refer to 「4.4 Input Condition Jump」.	-	0	255								
<b>JPT 1</b>			10000	10255								
			0	255								
<b>JPT 2</b>			10000	10255								
			0	255								
			10000	10255								
<table border="1"> <thead> <tr> <th>Input signal</th> <th>Corresponding Input Jump Position</th> </tr> </thead> <tbody> <tr> <td>JPT input0</td> <td>Input Jump Position No 0</td> </tr> <tr> <td>JPT input1</td> <td>Input Jump Position No 1</td> </tr> <tr> <td>JPT input2</td> <td>Input Jump Position No 2</td> </tr> </tbody> </table>		Input signal	Corresponding Input Jump Position	JPT input0	Input Jump Position No 0	JPT input1	Input Jump Position No 1	JPT input2	Input Jump Position No 2			
Input signal	Corresponding Input Jump Position											
JPT input0	Input Jump Position No 0											
JPT input1	Input Jump Position No 1											
JPT input2	Input Jump Position No 2											
<b>Loop Count</b>	If these item are specified, system repeats action of the position specified times (Loop Count) and after then jumps to corresponding position to Loop Jump Table No regardless of specified 'Jump Table No'. For more details, refer to 「4.5.1 Loop Setting」.	-	0	100								
<b>Loop Jump Table No.</b>			0	255								
			10,000	10,255								
<b>PT set</b>	Specifies output signals such as PT Output0, PT Output1, PT Output2 in order to confirm the start or stop of motor operation for each position.  0,8 : Not use output signal 1~7 : Specifies output function when starting operation 9~15 : Specifies output function when completing operation For more details, refer to 「4.6 Start/Completion Alarm Function」.		0	15								
<b>Loop Counter Clear</b>	If this item is checked, Loop Count of specified no of PT is to be cleared. For more details, refer to 「4.5.1 Loop Setting」.	-	0	255								
<b>Check Inpos</b>	If this item is checked, stop condition is recognized by Inposition finish.	-	0	1								

### 3.2 Type of Command

Item “Command” is for specifying type of action pattern to be executed for each position and the followings in the table are list of commands.

Command Name	Specified Value	Remark
Abs Move low speed.	0	The value in the item “Position” is value for absolute position.
Abs Move high speed	1	
Abs Move high speed with deceleration.	2	
Abs Move with acceleration and deceleration.	3	
Inc Move low speed.	4	The value in the item “Position” is value for relative position.
Inc Move high speed	5	
Inc Move high speed with deceleration.	6	
Inc Move with acceleration and deceleration.	7	
Move to Origin	8	Execute the command to move to origin based on the current parameters specified.
Clear Position	9	Reset ‘command position’ value and ‘actual position’ vale based on current position and clears the values as 0.

The following table shows speed patterns for each action of command.

Command Name	Specified Value	Speed Pattern
Abs Move low speed.	0	
Inc Move low speed.	4	
Abs Move high speed	1	
Inc Move high speed	5	
Abs Move high speed with deceleration.	2	
Inc Move high speed with deceleration.	6	
Abs Move with acceleration and deceleration.	3	
Inc Move with acceleration and deceleration.	7	

## 4. Execution of Position Table

When installing User Program(GUI), the following files are saved in the folder named as “[WWFASTECHWWEziMOTION PlusRWWPT\\_Samples](#)” as sample files to test Position Table.

- 1) [WWPT\\_SamplesWWEzi-SERVOWWPTsample \(General Motioning\).txt](#)
- 2) [WWPT\\_SamplesWWEzi-SERVO WWPTsample \(Loop Motioning\).txt](#)
- 3) [WWPT\\_SamplesWWEzi-SERVO WWPTsample \(Loop counter clear\).txt](#)
- 4) [WWPT\\_SamplesWWEzi-SERVO WWPTsample \(Clear Position\).txt](#)

### 4.1 How to start Position Table

Position Table operation is executed by input signal or communication command. The followings are example of Position Table operation by input signal to be explained step by step.

In the case of Position Table operation by communication command, the system is executed by sending the communication commands corresponding to the control input signal.


1. Specify Position Table No (0~255) operated by PT A0~PT A7.
2. If the motor is Servo OFF, turn ON Servo.
3. Signal ON of PTStart input to start operation.

### 4.2 Example for general operation

Specify PT No through input data for PT A0 ~ PT A7 and then input ‘PT Start’ signal to start speed control operation.

【Specifying Position Table】

PT No	Command type	Position	Low Speed	High Speed	Accel time	Decel. time	Wait time	Continuous Action	JP Table No.
0	3	10000	0	2500	50	300	0	1	1
1	0	1000	500	0	-	-	0	1	2
2	3	5000	0	1500	50	300	300	0	3
3	3	-2500	0	1000	300	300	0	0	-




\* Refer to the sample file for test Position Table, [‘PTsample \(General Motioning\).fpt’](#) .

## 4.3 Operation Modes

Position Table commands can be executed by two modes as follows.

### 4.3.1 Normal


Select 'Normal' at the main window of position table, and all commands will be in order executed by conditions entered to PT data.



- 1) While Normal mode is selected, the user sets PT number to 0 and click 'Run' and then PT 0 is executed.
- 2) PT 1 is executed by PT data jump conditions.
- 3) PT 2 is executed by PT data jump conditions.
- 4) As mentioned above, next PT number is automatically executed by position data jump conditions.
- 5) Click 'Stop' to stop operating.

### 4.3.2 Single Step

Select 'Single Step' at the main window of position table, and only corresponding PT command will be executed and next PT commands will be on standby. This mode can be easily used when the user executes the test for each position command. And it is available for User Program(GUI) only.



- 1) While Single Step Mode is selected, the user sets PT number to 0 and click 'Run' and then PT 0 is executed.
- 2) After execution is stopped, 'Run' icon is changed into 'Next' and next command is on standby.
- 3) Click 'Next' button, and PT 1 will be executed.
- 4) When pressing each 'Next' button, one PT command is executed.
- 5) Click 'Stop' to stopping operating. After operation is stopped, the user can set new PT number and click 'Run' button to start the program again.

## 4.4 Teaching Function


Teaching signal functions that the position value[pulse] being working can be automatically inputted into a 'position' value of a specific position table.

The following table shows type of commands and whether teaching function can be used or not.

Command Name	Value	To be used or not
Abs Move low speed.	0	'Teaching' can be used.
Abs Move high speed	1	
Abs Move high speed with deceleration.	2	
Abs Move with acceleration and deceleration.	3	
Inc Move low speed.	4	'Teaching' cannot be used.
Inc Move high speed	5	
Inc Move high speed with deceleration.	6	
Inc Move with acceleration and deceleration.	7	
Move to Origin	8	
Clear Position	9	

### 4.4.1 Teaching by user program

When click 'Teaching' button on Position Table screen, the following dialog box is activated.




- ① Select Position Table No, the figure shows that no 6 of PT is selected among 256 Position Tables.
- ② Specify position of motor where to teach and move it.
- ③ Turn ON or OFF of Servo during teaching.
- ④ Displays current position information and the value displayed in "Actual Pos(ition)" is to be teaching value.
- ⑤ When clicking this "Teaching" button, current value displayed in "Actual Pos" will be saved in the item "Position" of the current PT (No 6 above case). The values are to be saved on RAM and click 'Save to ROM' button in order to save on ROM.
- ⑥ In order to move next position, select PT no by using arrow keys.

#### 4.4.2 Teaching by Input signal

You can save current position information to the Position Table data by turning ON teaching control input signal. Also when executing teaching, position value (no. of pulse) is specified as absolute position value. Teaching is carried out by following orders:

1. Select PT no. to save data and specify items like "Command", etc.  
(except item 'Position')
2. Move motor to the position where you want to save data of it.
3. Specify PT no's that teaching is carried out by 'PT A0~PT A7'.
4. Turn ON teaching signal to save current position value into item 'Position' of Position Table data.
5. If you want to apply the saved value, you need to 'Refresh' PT data in order to verify the value on the User Program(GUI) screen.



PT No (CMD)	Position Value for each PT [pulse]
Position 3	12010
Position 4	15300
Position 12	-12800
Position 255	38520

## 4.5 Input Condition Jump

Among the items to be specified, “JP Table No.” , “JPT 0” , “JPT 1” and “JPT 2” are used for specifying next PT no. to be executed. In specifying next PT no. to be executed, there are two different methods depending on the control signal as followings:


### 4.5.1 Automatic Jump

This is the method to specify next action pattern (PT no.) by input condition. System jumps to next PT no. to be executed automatically according to procedure.

For example as shown in the following figure, when PT no. 14 is executing, 1) if there is no input signal, next action pattern is to be executed by PT no. 15 as shown in figure 1). However, if any of input signal is ON such as JPT Input0, JPT Input1 or JPT Input2 during the operation of PT no. 14, then system jumps to JPT 0, JPT 1 or JPT2 accordingly and execute it that is specified in the Position Table data as shown in the figure 2) ~ 4).

Data for PT no. 14

PT No (CMD)	Position Table No to jump (JP Table No.)	Input Jump Position No 0 (JPT 0)	Input Jump Position No 1 (JPT 1)	Input Jump Position No 2 (JPT 2)
14	15	115	116	225



\* Refer to the sample file for test Position Table, ‘PTsample (Loop Motioning).fpt’ .

## 4.5.2 Jump by External Signal

This is the method to specify next action pattern (PT no.) by input condition.

However, system does not jump to next PT no. to be executed automatically according to procedure, but executed by external signal ( "JPT Start" ).


Difference from the function in 'section 4.5.1' executed by input signal JPT Input0~Input2

- 1) Jump Position No to jump need to have the format of 10XXX and
- 2) 'JPT Start' needs to be [ON] in order to execute the next action.

If specified "Wait Time" of PT data is more than 0, then the next action is to be executed after the specified time from the external signal.

Data for PT no 14

PT No (CMD)	Wait Time (Wait Time)	Position Table No to jump (JP Table No.)	Input Jump Position No 0 (JPT 0)	Input Jump Position No 1 (JPT 1)	Input Jump Position No 2 (JPT 2)
14	0	10015	10115	10116	10225



## 4.6 Loop Condition Jump

### 4.6.1 Specifying Loop


If 「Loop Count」 and 「Loop Jump Table No」 are specified, system repeats the action of position specified times (Loop Count) and after then jumps to corresponding position to 「Loop Jump Table No. 」 regardless of specified 「Jump Position No」, that is, 「Jump Position No」 is ignored.

There are rules in specifying loop as following:

- 1) If '0' is specified for 「Loop Count」, loop function is cancelled.
- 2) If system needs to jump before repeating the specified times, it jumps to JP Table No.
- 3) If 'blank' is specified for 「Loop Jump Table No」, system exits execution.
- 4) If 「Loop Jump Table No」 is specified in the form of 10XXX, next action is executed by the external signal "JPT Start".

Following Table is one of example for specifying loop.

PT No (CMD)	Movement Scale (Position)	Position Table No to jump (JP Table No.)	No of Loop (Loop Count)	Position Table No to jump after completing loop (Loop Jump Table No)	Loop Counter Clear (Loop Counter Clear)
0	8000	1	0	0	-
1	4000	0	2	2	-
2	0	3	-	1	



\* Refer to the sample file for test Position Table, ['PTsample \(Loop Motioning\).fpt](#)

## 4.6.2 Loop Count Clear


“Loop Counter” is internal counter in drive to compare no. of repeat with the no. specified in the item “Loop Count” of PT data.

This function clears “Loop Counter” to 0 (zero) of the specified PT data after completion of looping. If 「Loop Count Clear」 is specified as blank, this function is cancelled.

Following table shows an example of specifying Loop Counter Clear.

PT No (CMD)	Movement Scale (Position)	Position Table No to jump (JP Table No.)	No of Loop (Loop Count)	Position Table No to jump after completing loop (Loop Jump Table No)	Loop Counter Clear (Loop Counter Clear)
0	8000	1	0	0	—
1	4000	0	2	2	—
2	0	0	0	0	1

- 1) Specify “Loop Counter Clear” of PT No 2 as PT No ‘1’ .
- 2) Start operation from PT No 0.  
When starting operation, system reset all “Loop Count” values as 0 (zero).
- 3) After repeats the loop block PT No 0 ~ PT No 1 two times, the “Loop Counter” becomes 2 (two) same as specified “Loop Count” and so system completes looping and jumps to PT No 2.
- 4) After executing PT No 2, system jumps to PT No 0.  
Before jumping to PT No 0, system clears “Loop Counter” – the internal counter as 0 (zero).
- 5) Then paragraph 3) and 4) are repeated infinitely.
- 6) If the “Loop Counter Clear” of PT No 2 was not specified, “Loop Counter” increased continuously and so jumping to PT No 2 occurs only once at the first time and then repeats the loop block PT No 0 ~ PT No 1 infinitely because the internal counter “Loop Counter” value will never meet the specified “Loop Count” value.



\* Refer to the sample file for test Position Table, [‘PTsample \(Loop counter clear\).fpt](#).

## 4.7 Start/Completion Signal Function


By specifying the item 「Start/Completion Signal Function」, user can recognize the status of Position Table whether it started operation, is under operation, or completed operation through control signal output.

If you do not want to use 「Start/Completion Signal Function」, specify this item as 0 or 8.

If other value is specified, the position performs following actions depending on specified value.

- If the value between 1 to 7 is specified for PT Set, PT Output HEX value is output through output of 'PT Output 0 ~ PT Output 2' at the time of starting operation.
- If the value between 9 to 15 is specified for PT Set, PT Output HEX value is output through output of 'PT Output 0 ~ PT Output 2' after completion of operation.

PT Set Value	PT Output 2 Signal	PT Output 1 Signal	PT Output 0 Signal	PT Output HEX Value	Function
0	OFF	OFF	OFF	0	Not use output function of PT Output 0~2.
1	OFF	OFF	ON	1	PT Output 0~2 signals turn to [ON] at the time of starting operation of the corresponding PT.
2	OFF	ON	OFF	2	
3	OFF	ON	ON	3	
4	ON	OFF	OFF	4	
5	ON	OFF	ON	5	
6	ON	ON	OFF	6	
7	ON	ON	ON	7	
8	OFF	OFF	OFF	0	Not use output function of PT Output 0~2.
9	OFF	OFF	ON	1	PT Output 0~2 signals turn to [ON] after completion of operation of the corresponding PT.
10	OFF	ON	OFF	2	
11	OFF	ON	ON	3	
12	ON	OFF	OFF	4	
13	ON	OFF	ON	5	
14	ON	ON	OFF	6	
15	ON	ON	ON	7	





## **FASTECH Co., Ltd.**

Rm #1403, Bucheon Technopark 401 Dong,  
Yakdae-dong, Wonmi-Gu, Bucheon-si,  
Gyeonggi-do, Rep. Of Korea (Zip:420-734)  
TEL : 82-32-234-6300  
FAX : 82-32-234-6302

Email : [fastech@empal.com](mailto:fastech@empal.com)  
Homepage : [www.fastech.co.kr](http://www.fastech.co.kr)

- Please note that the specifications are subject to change without notice due to product improvements.

© Copyright 2008 FASTECH Co.,Ltd.

All Rights Reserved. May 15, 2009 rev.04.01.02