

Software Manual

Liberty MDrive Ethernet TCP/IP

Open Loop • Closed Loop • Absolute Encoder

MODBUS/TCP

User's Manual

Publication LMD-MODBUS-REV-D

02/2022



Modbus



US

CE



REACH



Novanta
IMS

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof.

Neither Novanta IMS nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

You agree not to reproduce, other than for your own personal, noncommercial use, all or part of this document on any medium whatsoever without permission of Novanta IMS, given in writing. You also agree not to establish any hypertext links to this document or its content.

Novanta IMS does not grant any right or license for the personal and non-commercial use of the document or its content, except for a non-exclusive license to consult it on an "as is" basis, at your own risk. All other rights are reserved.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed. Failure to use Novanta IMS software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

For information on the availability of products, go to <https://novantaims.com/>

The information contained in the present document is subject to change without notice. The technical characteristics of the devices described in the present document also appear online. The characteristics that are presented in the present document should be the same as those characteristics that appear online. In line with our policy of constant improvement, we may revise content over time to improve clarity and accuracy. If there is a difference between the document and online information, use the online information as reference. All details provided are technical data which do not constitute warranted qualities.

Some of the product designations are registered trademarks of their respective owners, even if this is not explicitly indicated.

Table of Contents

	About this manual	5
	Further reading.....	5
1	Introduction.....	6
	1.1 About this manual.....	6
	1.2 Supported protocols	6
	1.3 Documentation reference	7
	1.4 Product software	7
	1.4.1 Lexium MDrive Software Suite	7
2	Safety.....	8
	2.1 Qualification of personnel.....	8
	2.2 Intended Use	8
	2.3 Hazard Categories	9
	2.4 Basic information.....	10
3	MODBUS Implementation	11
	3.1 MODBUS overview	11
	3.2 Message format.....	12
	3.2.1 ADU (application data unit).....	13
4	Function codes	15
	4.1 Device ID.....	15
	4.1.1 Read device identification – 43/14 (0x2B/0x0E).....	15
	4.2 Public function codes	17
	4.2.1 Read digital inputs 02 (0x02)	17
	4.2.2 Read coils (digital outputs) – 01 (0x01)	18
	4.2.3 Write single coil (digital output) – 05 (0x05).....	19
	4.2.4 Read holding registers – 03 (0x03).....	20
	4.2.5 Write multiple registers – 16 (0x10)	21
	4.3 Manufacturer specific function codes	22
	4.3.1 Read manufacturer specific – 65 (0x41).....	23
	4.3.2 Write manufacturer specific – 66 (0x42)	24
	4.4 Mfg Specific Function Code Details	25
	4.4.1 Escape <ESC>	25
	4.4.2 Attention output setup	25
	4.4.3 Clear program	26
	4.4.4 Encoder line count.....	26
	4.4.5 Execute program	26
	4.4.6 Input setup	27
	4.4.7 Read internal temperature.....	28
	4.4.8 Make up mode	28
	4.4.9 Output setup	29
	4.4.10 Pause program	30
	4.4.11 Resume program	30
	4.4.12 Read voltage level	30
	4.4.13 End program execution.....	30
	4.4.14 Read/set rotation of direction.....	31
	4.4.15 Read/set acceleration jerk	31
	4.4.16 Read/set acceleration type	31
	4.4.17 Read/set backlash enable	32
	4.4.18 Read/set backlash amount	32
	4.4.19 Read/set backlash mode	32

4.4.20	Read/set deceleration jerk	33
4.4.21	Read/set deceleration type	33
4.4.22	Read/set index offset	33
4.4.23	Home to index offset	34
4.4.24	hMT actual velocity	34
4.4.25	Following mode enable	34
4.4.26	Software limits	34
4.4.27	Upgrade	35
5	Register map	36
5.1	hMTechnology specific registers (Closed loop only)	40
5.2	User variable registers	42
6	TCP/IP Configuration Utility	43
	Warranty	44
	Document Revision History	44

List of Figures

Figure 3.1:	Example MODBUS network with LMD products	11
Figure 3.2:	Client-server model	12
Figure 3.3:	Construction of an ethernet data packet for MODBUS/ TCP	12
Figure 3.4:	MODBUS/TCP data packet construction	13

About this manual

The information provided in this manual supplements the product hardware manual.

Source manuals The latest versions of the manuals can be downloaded from the Internet at: <https://novantaims.com/dloads/>

Applicable manuals for Liberty MDrive (LMD) Ethernet products are:

- LMD MCode Programming and Software Reference manual
- MODBUS/TCP Fieldbus manual
- EtherNet/IP (EIP) Fieldbus manual
- LMD Software Suite (LSS) Manual

Graphic User Interface software For easier prototyping and development, a Graphic User Interface (GUI) is available for use with LMD products. This software is available for download from: <https://novantaims.com/dloads/>

Further reading

Recommended literature for further reading.

Reference documents The MODBUS Specification and Implementation guides
<http://www.modbus.org/specs.php>

The MODBUS/TCP toolkit: <http://www.modbus.org/toolkit.php>

User Association MODBUS Organization: <http://www.modbus.org/>

1 Introduction

1.1 About this manual

This manual is for use with the LMD Ethernet models when the Modbus/TCP protocol is needed. This manual was developed from the perspective that you already have an understanding of the MODBUS protocol.

For detailed technical information on the MODBUS/TCP specification, see <http://www.modbus.org/>.

1.2 Supported protocols

The new LMD Ethernet products support three protocols in a single package:

- 1) **EtherNet/IP** — EtherNet/IP protocol popularized by Allen Bradley and Rockwell Automation and managed by the ODVA.

If using the device using MCode/TCP, please see the EtherNet/IP Fieldbus Manual available for download from:
<https://novantaims.com/dloads/>.

- 2) **MCode/TCP** — Schneider Electric Motion USA's proprietary programming language for Lexium MDrive Ethernet products, adapted to utilize TCP/IP message formatting.

If using the device using MCode/TCP, please see the MCode Programming and Reference Manual located on the web site at
<https://novantaims.com/dloads/>

- 3) **MODBUS/TCP** — A standard open industrial protocol supported by a variety of machine components such as programmable controllers, drives and controls, I/O modules and switches.

These protocols may be used separately or interchangeably, as is required by the constraints of the application by connecting to the port that the protocol is running on, 503 for MCode/TCP and 502 for MODBUS/TCP.

First configuration connection will need to be over MCode/TCP using the Ethernet Interface, which is part of the LSS to change the IP address of the device. The Suite and it's associated manual may be downloaded from: <https://novantaims.com/dloads/>

The Information on MCode is found in the MCode Programming and Software Reference available for download from:
<https://novantaims.com/dloads/>

1.3 Documentation reference

The following user's manuals are available for the MODBUS devices:

- Product hardware manual, describes the technical data and installation of the product.
- Product software manual, describes the configuration and programming of the product.
- Quick Reference, describes the basic wiring, connection and use of this product. The quick reference is shipped in printed form with the product.

This documentation is also available for download from:

<https://novantaims.com/dloads/>

1.4 Product software

1.4.1 Lexium MDrive Software Suite

The Ethernet Interface is a software tool for setting the IP, upgrading firmware and sending commands to the MODBUS device. It is part of the LSS. This software is required for the initial setup of the device.

Installation and usages instructions are to be found in LSS Manual.

This software and manual may be downloaded from:

<https://novantaims.com/dloads/>.

2 Safety

2.1 Qualification of personnel

Only appropriately trained persons who are familiar with and understand the contents of this manual and all other pertinent product documentation are authorized to work on and with this product. In addition, these persons must have received safety training to recognize and avoid hazards involved. These persons must have sufficient technical training, knowledge and experience and be able to foresee and detect potential hazards that may be caused by using the product, by changing the settings and by the mechanical, electrical and electronic equipment of the entire system in which the product is used.

All persons working on and with the product must be fully familiar with all applicable standards, directives, and accident prevention regulations when performing such work.

2.2 Intended Use

The functions described in this manual are only intended for use with the basic product; you must read and understand the appropriate product manual.

The product may only be used in compliance with all applicable safety regulations and directives, the specified requirements and the technical data.

Prior to using the product, you must perform a risk assessment in view of the planned application. Based on the results, the appropriate safety measures must be implemented.

Since the product is used as a component in an entire system, you must ensure the safety of persons by means of the design of this entire system (for example, machine design).

Operate the product only with the specified cables and accessories. Use only genuine accessories and spare parts.

Any use other than the use explicitly permitted is prohibited and can result in hazards.

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel.

The product must NEVER be operated in explosive atmospheres (hazardous locations, Ex areas).and spare parts.

2.3 Hazard Categories

Safety instructions to the user are highlighted by safety alert symbols in the manual. In addition, labels with symbols and/or instructions are attached to the product that alert you to potential hazards.

Depending on the seriousness of the hazard, the safety instructions are divided into 4 hazard categories.

DANGER

DANGER indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury.

WARNING

WARNING indicates a potentially hazardous situation, which, if not avoided, **can result** in death, serious injury, or equipment damage.

CAUTION

CAUTION indicates a potentially hazardous situation, which, if not avoided, **can result** in injury or equipment damage.

CAUTION

CAUTION used without the safety alert symbol, is used to address practices not related to personal injury (e.g. **can result** in equipment damage).

2.4 Basic information

▲ DANGER

UNINTENDED CONSEQUENCES OF EQUIPMENT OPERATION

When the system is started, the drives are usually out of the operator's view and cannot be visually monitored.

- Only start the system if there are no persons in the hazardous area.

Failure to follow these instructions will result in death or serious injury.

▲ WARNING

LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop, overtravel stop, power outage and restart.
- Separate or redundant control paths must be provided for critical functions.
- System control paths may include communication links. Consideration must be given to the implication of unanticipated transmission delays or failures of the link.
- Observe all accident prevention regulations and local safety guidelines. 1)
- Each implementation of the product must be individually and thoroughly tested for proper operation before being placed into service.

Failure to follow these instructions can result in death or serious injury.

1) For USA: Additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control" and to NEMA ICS 7.1 (latest edition), "Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable-Speed Drive Systems".

3 MODBUS Implementation

3.1 MODBUS overview

MODBUS is a communications interface developed in 1979 by PLC manufacturer Modicon, Inc.. MODBUS is designed for multidrop networks based on a master-client architecture.

The availability of devices using MODBUS has made it a de facto standard for industrial communications network. MODBUS was originally developed for use with serial communications interfaces such as RS-232 and RS-485, MODBUS/TCP communications over TCP/IP has become a standard because of the ease of interface and simpler message format.




Figure 3.1: Example MODBUS network with LMD products.

MODBUS/TCP is basically the MODBUS serial RTU encapsulated in a TCP/IP wrapper and is used for TCP/IP communications between client and server devices on an Ethernet TCP/IP network.




Figure 3.2: Client-server model

3.2 Message format

MODBUS/TCP uses the OSI (Open Systems Interconnection) networking model. The MODBUS ADU (Application Data Unit) makes up the OSI application layer and is wrapped inside the data array of the TCP/IP Ethernet data packet. Figure 3.3 below shows the construction of a TCP/IP Ethernet data packet used for the MODBUS/TCP protocol.




Figure 3.3: Construction of an ethernet data packet for MODBUS/TCP

3.2.1 ADU (application data unit)

A MODBUS/TCP data packet, or Application Data Unit (ADU) consists of two components:

- 1) MODBUS Application Protocol (MBAP) header
- 2) Protocol Data Unit (PDU)

The information contained in the ADU is embedded in the data portion of the TCP frame.




Figure 3.4: MODBUS/TCP data packet construction

MBAP header

The MBAP header is 7 bytes long and consists of the following fields made up of four fields”

Fields	Length	Description
Transaction identifier	2 bytes	ID of a MODBUS request/response transaction. This field is used for transaction pairing, the server will copy in the Transaction ID of the request into the response.
Protocol identifier	2 bytes	0 = MODBUS protocol
Length	2 bytes	Number of bytes following, including the Unit ID and the byte length of the PDU.
Unit identifier	1 byte	ID of a remote slave. Used for intra-system communications with other buses i.e. between MODBUS/TCP and a MODBUS serial line slave through a gateway.

Table 3.1 MBAP header

Protocol Data Unit (PDU) The PDU consists of 2 parts:

- 1) **Function code:** the function code identifies the action to be taken using the data bytes that will follow. These functions are covered in detail in Section 4 of this document. Basic functions are:
Reading inputs, writing coils (digital outputs), read/write registers and manufacturer specific configuration functions.
- 2) **Data:** The data contained in the PDU, it will consist of the data and/or parameters associated with the commands to operate your LMD product.

4 Function codes

The LMD supports the following function codes:

Function code		Description
dec	hex	
Device ID		
43/14	0x2B/0x0E	Read device identification
Public		
02	0x02	Read digital inputs
01	0x01	Read coils (digital outputs)
05	0x05	Write single coil (digital output)
03	0x03	Read holding register
16	0x10	Write multiple registers
Manufacturer specific		
65	0x41	Read specific functions
66	0x42	Write specific functions

Table 4.1: Supported function codes

Exception codes

Each function has 4 error, or exception codes that will return in case of an error with the transaction. They are:

- 01 – Illegal or not supported function
- 02 – Illegal data address
- 03 – Illegal data value
- 04 – Slave device failure

4.1 Device ID

4.1.1 Read device identification – 43/14 (0x2B/0x0E)

The device type contains information about your LMD product, importantly the part number, serial number, and firmware version installed.

Request	Length	Value
Function code	1 byte	0x2B
MEI* type	1 byte	0x0E
Read device ID code	1 byte	01 / 02 / 03 / 04
Object ID	1 byte	0x00 – 0x06

*MODBUS Encapsulated Interface

Response

	Length	Value
Function code	1 byte	0x2B
MEI type	1 byte	0x0E
Read device ID code	1 byte	
Conformity level	1 byte	
More follows	1 byte	
NextObjectId	1 byte	0x00
Number Of Objects	1 byte	0x06
Object Id	1 byte	0x00
Object Length	1 byte	0x03
Object Value	3 bytes	"IMS USA"
Object Id	1 byte	0x01
Object Length	1 byte	0xXX
Object Value	X bytes	"LMDxExxx"
Object Id	1 byte	0x02
Object Length	1 byte	0x08
Object Value	8 bytes	"4.0.0.0"
Object Id	1 byte	0x03
Object Length	1 byte	0x20
Object Value	32 bytes	"https://novantaims.com/"
Object Id	1 byte	0x04
Object Length	1 byte	0x0A
Object Value	10 bytes	LMD Ethernet
Object Id	1 byte	0x05
Object Length	1 byte	0xXX
Object Value	X bytes	"Serial number"
Object Id	1 byte	0x06
Object Length	1 byte	0x0C
Object Value	12 bytes	LMDCM X.XXX, Hw: X.X

4.2 Public function codes

4.2.1 Read digital inputs 02 (0x02)

Function 02 is used to read the state of the digital inputs 1 - 4 on your LMD product. The request PDU contains the starting address of the first input specified, and the number of inputs.

In the response message the input states are packaged as 1 input per bit of the data field where status is indicated as 1 = ON and 0 = OFF. The LSB of the data byte will be the address of the input in the request.

NOTE: Digital inputs on the LMD may also be read using the holding registers.

NOTE 2: The inputs must be configured as such using the manufacturer specific function code 66 (0x42).

Request

	Length	Value
Function code	1 byte	0x02
Starting Address	2 bytes	0x0000 – 0x0003
Quantity of inputs	1 byte	1 to 4

Response

	Length	Value
Function code	1 byte	0x02
Byte Count	1 byte	1 to 4
Input status	1 to 4 bytes	

Error

	Length	Value
Error code	1 byte	0x82
Exception	1 byte	01, 02, 03 or 04
Input status	1 to 4 bytes	

Example

Example shows a read of all 4 LMD digital inputs, the response shows input states: I1=1, I2=1, I3=0, I4=1. Input 1 is the input address and is therefore the LSB,

Request		Response	
Function	0x02	Function	0x02
Starting address Hi	0x00	Byte count	0x01
Starting address Lo	0x2D	Input status 4 – 1	0x0F
Qty of inputs Hi	0x00		
Qty of inputs Lo	0x04		

4.2.2 Read coils (digital outputs) – 01 (0x01)

Function 01 is used to read the state of the digital outputs 1 - 4 on your LMD product. The request PDU contains the starting address of the first output specified, and the number of outputs.

In the response message the output states are packaged as 1 output per bit of the data field where status is indicated as 1 = ON and 0 = OFF. The LSB of the data byte will be the output of the address in the request.

NOTE: Digital outputs on the LMD may also be read using the holding registers.

NOTE 2: The outputs must be configured as such using the manufacturer specific function code 66 (0x42).

Request

	Length	Value
Function code	1 byte	0x01
Starting Address	2 bytes	0x0000
Quantity of outputs	1 byte	1 to 4

Response

	Length	Value
Function code	1 byte	0x01
Byte Count	1 byte	1 to 4
Input status	1 to 4 bytes	

Error

	Length	Value
Error code	1 byte	0x81
Exception	1 byte	01, 02, 03 or 04
Input status	1 to 4 bytes	

Example

Example shows a read of all 4 LMD digital outputs, the response shows outputs states: O1=1, O2=0, O3=1, O4=0. Output 1 is the output address and is therefore the LSB,

Request		Response	
Function	0x01	Function	0x02
Starting address Hi	0x00	Byte count	0x01
Starting address Lo	0x00	Output status 4 – 1	0x00
Qty of outputs Hi	0x00		
Qty of outputs Lo	0x04		

4.2.3 Write single coil (digital output) – 05 (0x05)

This function is used to turn a single output point ON or OFF.

The state is specified by a constant in the request data field:

- 0xFF00 – turns the output ON
- 0x0000 – turns the output OFF

All other values are illegal and will return an exception code 03: Illegal data value.

NOTE: Digital outputs on the LMD may also be written using the holding registers.

NOTE 2: The outputs must be configured as such using the manufacturer specific function code 66 (0x42).

Request

	Length	Value
Function code	1 byte	0x05
Output address	2 bytes	0x0000 – 0x0003
Output value	2 bytes	0x0000 or 0xFF00

Response

	Length	Value
Function code	1 byte	0x05
Output address	2 bytes	0x0000 – 0x0003
Output value	2 bytes	0x0000 or 0xFF00

Error

	Length	Value
Error code	1 byte	0x85
Exception	1 byte	01, 02, 03 or 04

Example

Example shows setting output 3 to an ON state.

Request		Response	
Function	0x05	Function	0x05
Output address Hi	0x00	Output address Hi	0x00
Output address Lo	0x00	Output address Lo	0x00
Output value Hi	0xFF	Output value Hi	0xFF
Output value Lo	0x00	Output value Lo	0x00

4.2.4 Read holding registers – 03 (0x03)

This function code is used to read a contiguous block of holding registers in the LMD. The request PDU specifies the starting register address and the number of registers.

LMD command data mapped to the holding registers measure 1, 2 or 4 bytes in length, therefore you will not need to read more than two consecutive registers per request.

NOTE: A number of registers are marked as reserved. Use of any of these registers will return a exception code 02: illegal data address.

See Section 5 of this document for the register map.

Request

	Length	Value
Function code	1 byte	0x03
Starting address	2 bytes	0x0000 – 0x00B7*
Each address	2 bytes	1 to 2

*A number of addresses in this block are reserved for future use and will return an error.

Response

	Length	Value
Function code	1 byte	0x03
Byte count	2 bytes	1 – 4
Register value	2 bytes	0x00 to 0x04

Error

	Length	Value
Error code	1 byte	0x83
Exception	1 byte	01, 02, 03 or 04

Example

Example shows reading registers 0x008A and 0x008B (maximum velocity). The value reads as 0x00 0B B8 00 or decimal 768000 steps/second.

Request		Response	
Function	0x03	Function	0x0F
Starting address Hi	0x00	Byte count	0x04
Starting address Lo	0x8B	Register value Hi	0xB8
Qty of registers Hi	0x00	Register value Lo	0x00
Qty of registers Lo	0x02	Register value Hi	0xB8
		Register value Lo	0x0B

4.2.5 Write multiple registers – 16 (0x10)

This function code is used to write a contiguous block of registers in your LMD. The request PDU specifies the starting register address and the number of registers to be written.

LMD command data mapped to the registers measure 1, 2 or 4 bytes in length, therefore you will not need to write more than two consecutive registers per request.

NOTE: A number of registers are marked as reserved. Use of any of these registers will return an exception code 02: illegal data address.

See Section 5 of this document for the register map.

Request

	Length	Value
Function code	1 byte	0x10
Starting address	2 bytes	0x0000 – 0x00B7*
Each address	2 bytes	1 to 2
Qty of addresses	1 byte	2 or 4
Registers value	to 4 bytes	value

*A number of addresses in this block are reserved for future use and will return an error.

Response

	Length	Value
Function code	1 byte	0x10
Starting address	2 bytes	0x0000 – 0x00B7*
Qty of registers	2 bytes	0x0001 to 0x0002

Error

	Length	Value
Error code	1 byte	0x90
Exception	1 byte	01, 02, 03 or 04

Example

Example shows writing registers 0x008A and 0x008B (maximum velocity). The value will be set as decimal 600000 steps/second, or 0x00 09 27 C0.

Request		Response	
Function	0x10	Function	0x10
Starting address Hi	0x00	Starting address Hi	0x00
Starting address Lo	0x8A	Starting address Lo	0x8A
Qty of registers Hi	0x00	Qty of registers Hi	0x00
Qty of registers Lo	0x8B	Qty of registers Lo	0x8B
Byte count	0x04		
Registers value Hi	0x27		
Registers value Lo	0xC0		
Registers value Hi	0x00		
Registers value Lo	0x09		

4.3 Manufacturer specific function codes

The device supports two manufacturer specific function codes:

- 65 (0x41) – Read specific functions
- 66 (0x42) – Write specific functions

These function codes allow the user to read/write formatted configuration and status information such as I/O point setup, device temperature or voltage information and etc.

Manufacturer functions

Function	Mnemonic	ASCII	R/W
<ESC>	<ESC>	0x001B20	W/O
Attention output	AO	0x004F41	R/W
Clear MCode program space	CP	0x005043	W/O
Encoder line count	EL	0x004C45	R/W
Execute program	EX	0x205845	W/O
Setup input points 1 – 4	IS	0x005349	R/W
Read internal temperature	IT	0x005449	R/O
Make-up mode	MU	0x00554D	R/W
Setup output points 1 – 3	OS	0x00534F	R/W
Pause running program	PS	0x205350	W/O
Resume paused program	RS	0x205352	W/O
<i>Use of the below listed function codes requires MCode Operating System version 6.004 or greater.</i>			
Reverse direction	RD	0x204452	R/W
Acceleration jerk	AJ	0x204A41	R/W
Acceleration type	AT	0x205441	R/W
Backlash enable	BE	0x204542	R/W
Backlash amount	BL	0x204C42	R/W
Backlash mode	BM	0x204D42	R/W
Deceleration jerk	DJ	0x204A44	R/W
Deceleration type	DT	0x205444	R/W
Index offset amount	FS	0x205346	R/W
Home to index offset	HF	0x204648	W/O
hMT actual velocity	AV	0x205641	R/O
Following mode enable	FL	0x204C46	R/W
Software limits	LS	0x20534C	R/W
Upgrade mode	UG	0x204755	W/O
Read voltage	VT	0x005456	R/O

4.3.1 Read manufacturer specific – 65 (0x41)

Request

	Length	Value
Function code	1 byte	0x41
Mnemonic Hi word	2 bytes	0x2020 0x2020/2033*
Mnemonic Lo word	2 bytes	See section 4.3.1 for listing

*For capture/trip I/O point.

Response

	Length	Value
Function code	1 byte	0x41
Byte count	2 bytes	N* (quantity of characters returned)
Response	n bytes	n=N or N+1

Error

	Length	Value
Error code	1 byte	0xC1
Exception	1 byte	01, 02, 03 or 04

Example Example shows reading the setting of the trip on relative input (TR).

Request		Response	
Function	0x41	Function	0x41
Mnemonic Hi word	0x20	Byte count	0x07
	0x20	Response	0x30
Mnemonic Lo word	0x52		0x2C
	0x54		0x20
			0x30
			0x2C
			0x20
			0x30

4.3.2 Write manufacturer specific – 66 (0x42)

Request

	Length	Value
Function code	1 byte	0x42
Mnemonic Hi word	2 bytes	0x2020 0x2020/2033*
Mnemonic Lo word	2 bytes	See section 4.3.1 for listing
Byte count	1 byte	1-n bytes (28 max)
Parameter data string	n bytes	See section 4.3.1 for listing

*For capture/trip I/O point.

Response

	Length	Value
Function code	1 byte	0x42
Byte count written	1 bytes	N* (quantity of characters returned)
Mnemonic Hi word	2 bytes	0x2020 0x2020/2033*
Mnemonic Lo word	2 bytes	See section 4.3.1 for listing

Error

	Length	Value
Error code	1 byte	0xC2
Exception	1 byte	01, 02, 03 or 04

Example

Example shows setting input 1 (S1). The input is shown set to a general purpose sinking input which is active when Hi, or S1=0,1,0. Note that the data string includes all of the characters, including the equal sign and the commas.

Request		Response	
Function	0x41	Function	0x41
Mnemonic Hi word	0x20	Bytes written	0x04
	0x20	Mnemonic Hi word	0x20
Mnemonic Lo word	0x31		0x20
	0x53	Mnemonic Lo word	0x31
Byte count	0x06		0x53
Parameter data string	0x3D		
	0x30		
	0x2C		
	0x31		
	0x2C		
	0x30		

4.4 Mfg Specific Function Code Details

4.4.1 Escape <ESC>

Send an escape <ESC>

Function	66 (0x42) Write Mfg Spc	
MCode mnemonic	<ESC>	
Mnemonic	Hi word	0x20 0x20
	Lo word	0x1B 0x20
Parameter data length	0 bytes	

4.4.2 Attention output setup

The ASCII of the command mnemonic is sent in reverse order in the request PDU
The parameter string is written or read in normal sequence.

Function	65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc	
MCode mnemonic	AO (Attention output)	
Mnemonic	Hi word	0x20 0x20
	Lo word	0x4F 0x41
Parameter data length	2 – 6 bytes	
	ASCII	= 1 2
	Hex	3D 31 32

Parameters

Mask	Condition	LED color
1	Error flag	Red
2	Locked rotor*	Red
4	Lead limit*	Red
8	Lag limit*	Red
16	hMT active*	Red
32	Calibration active*	Red
64	Over temperature	Red
128	Software error	Red
256	At zero cross	Red
512	Current reduction active	Red
1024	Make-up active*	Red
2048	Drive disabled (DE=0)*	Red
4096	Warning temperature	Red
8192	Voltage warning	Red
16384	Moving flag	Red
32768	Stall flag*	Red

4.4.3 Clear program

Clears MCode program space.

Function		66 (0x42) Write Mfg Spc
MCode mnemonic		CP (Clear program)
Mnemonic	Hi word	0x20 0x20
	Lo word	0x50 0x43
Parameter data length		0 bytes

4.4.4 Encoder line count

Set/read the line count of the encoder.

Note: Not applicable to LMD integrated products..

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc				
MCode mnemonic		EL (Encoder line count)				
Mnemonic	Hi word	0x20 0x20				
	Lo word	0x4C 0x45				
Parameter data length		5 bytes				
	ASCI	=	1	0	0	0
	Hex	3D	31	30	30	30

4.4.5 Execute program



Executes the address or label of a stored MCode/TCP program.

NOTE: The program resident CANNOT have any print statements in the code.

User variables that need to be read over MODBUS/TCP during program execution must be read using Registers R1 – R4 and V1 – V8 using the associated register (See Section 5: Register Map). If using V1 – V8, they must be declared within the program using the VA (Create user variable) MCode command.

The example below shows the programmed labeled G1 being executed.

Function		66 (0x42) Write Mfg Spc			
MCode mnemonic		EX (Execute program			
Mnemonic	Hi word	0x20 0x20			
	Lo word	0x58 0x45			
Parameter data length		up to 4 bytes			
	ASCI	G	1		
	Hex	20	47	31	

4.4.6 Input setup

Set or read the configuration of an input.

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc					
MCode mnemonic		Is (Input setup)					
Mnemonic	Hi word	0x20 0x20					
	Lo word	0x53 0x49					
Parameter data length		6 – 7 bytes					
Parameter string example	Params	A		B		C	
	ASCII	=	0	,	0	,	0
	Hex	3D	30	2C	30	2C	30

Parameters

A – Line number		B – I/O type			C – Active Hi/Lo		
Input		Input functions					
dec	hex	dec	hex	function	dec	hex	
1	31	0	30	General purpose	0	30	Active Lo
2	32	1	31	Homing	1	31	Active Hi
3	33	2	32	Limit +			
4	34	3	33	Limit –			
		5	35	Soft stop			
		7	37	Jog +			
		8	38	Jog –			
		11	31 31	Reset			
		12	31 32	Capture input			

■ = Not applicable to NEMA 17 models

Analog input setup

The ASCII of the command mnemonic is sent in revers order in the request PDU i.e. SI. The parameter string is written or read in normal sequence.

The analog input may be configured for voltage or current mode with ranges of 0 to 5 VDC, 0 to 10 VDC, 0 to 20 mA or 4 to 20 mA.

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc						
MCode mnemonic		Is (Analog Input)						
Mnemonic	Hi word	0x20 0x20						
	Lo word	0x53 0x49						
Parameter data length		4 – 5 bytes						
Parameter string example	Params	A		B		C		See parameters table below for details
	ASCII	=	5	,	9	,	0	
	Hex	3D	35	2C	39	2C	30	

See parameters table below for details

Parameters

A – Input mode			B – Input range		
dec	hex	mode	dec	hex	range
9	39	Voltage	0	30	0 – 5 VDC
			1	31	0 – 10 VDC
10	31 30	Current	0	30	0 – 20 mA
			1	31	4 – 20 mA

4.4.7 Read internal temperature

Read the internal temperature of the device. Will return two values: The output bridge temperature and the microprocessor temperature.

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc				
MCode mnemonic		IT (Internal temperature)				
Mnemonic	Hi word	0x20 0x20				
	Lo word	0x54 0x49				
Parameter data length		5 bytes				
	ASCI	5	2	,	3	7
	Hex	35	32	2C	33	37

4.4.8 Make up mode

Set or read the mode of operation for position make up.

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc			
MCode mnemonic		MU (Make up mode)			
Mnemonic	Hi word	0x20 0x20			
	Lo word	0x55 0x4D			
Parameter data length		6 – 7 bytes			
	Params	A	B		
	ASCII	=	1	,	0
	Hex	3D	31	2C	30

Parameters

A - Mode			B– Lead/lag operation		
dec	hex	function	dec	hex	function
0	30	Off (default)	0	30	Use lead/lag (0x0099)
1	31	Use make up frequency (See register 0x009E - MF)	1	31	Clear lead/lag (0x0099)
2	32	Use system speed			

4.4.9 Output setup

The ASCII of the command mnemonic is sent in reverse order in the request PDU i.e. SO etc. The parameter string is written or read in normal sequence.

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc					
MCode mnemonic		Os(Output setup)					
Mnemonic	Hi word	0x20 0x20					
	Lo word	0x53 0x4F					
Parameter data length		6 – 7 bytes					
Parameter string example	Params	A		B		C	
	ASCII	=	0	,	0	,	0
	Hex	3D	30	2C	30	2C	30

Parameters

A - Line number		B- I/O type			C – Active Hi/Lo		
Output		Output Functions					
1	31	16	31 36	General purpose	dec	hex	
2	32	17	31 37	Moving	0	30	Active Lo
3	33	18	31 38	Fault	1	31	Active Hi
		20	32 30	Velocity changing			
		21	32 31	Locked rotor			
		23	32 33	Moving to position			
		24	32 34	hMTechnology active			
		25	32 35	Make-up active			
		26	32 36	Reserved			
		27	32 37	Reserved			
		28	32 38	Trip (Output 3 only)			
		29	32 39	Attention			

 = Not applicable to NEMA 17 models

4.4.10 Pause program

Pause a running MCode program.

Function		66 (0x42) Write Mfg Spc
MCode mnemonic		PS (Pause program)
Mnemonic	Hi word	0x20 0x20
	Lo word	0x53 0x50
Parameter data length		0 bytes

4.4.11 Resume program

Resume a paused MCode program.

Function		66 (0x42) Write Mfg Spc	
MCode mnemonic		RS (Resume program)	
Mnemonic	Hi word	0x20 0x20	
	Lo word	0x53 0x52	
Parameter data length		0 bytes	

4.4.12 Read voltage level

Read the voltage of the device. Will return two values: The Auxiliary voltage and the +V voltage level.

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc				
MCode mnemonic		VT (Read voltage)				
Mnemonic	Hi word	0x20 0x20				
	Lo word	0x54 0x56				
Parameter data length		5 bytes				
	ASCI	2	2	,	3	7
	Hex	32	32	2C	33	37

4.4.13 End program execution

Stops the execution of a program.

Function		66 (0x42) Write Mfg Spc	
MCode mnemonic		E (Stop program execution)	
Mnemonic	Hi word	0x20 0x20	
	Lo word	0x20 0x45	
Parameter data length		0 bytes	

NOTE: The function codes detailed in subsections 4.4.14 and greater support features added to MCode Operating System 6.004. Use of these function codes in earlier versions of the MCode OS will return an error

4.4.14 Read/set rotation of direction

Read or set the reverse direction bit

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc
MCode mnemonic		RD (Rotation of Direction)
Mnemonic	Hi word	0x20 0x20
	Lo word	0x44 0x52
Parameter data length		2 bytes
	ASCII	= 1
	Hex	3D 31

4.4.15 Read/set acceleration jerk

Read or set the acceleration jerk for S-curve acceleration types

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc
MCode mnemonic		AJ (Acceleration Jerk)
Mnemonic	Hi word	0x20 0x20
	Lo word	0x4A 0x41
Parameter data length		up to 4 bytes
	ASCII	= 1 2 8
	Hex	3D 31 32 38

4.4.16 Read/set acceleration type

Read or set the acceleration type for S-curve acceleration types

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc
MCode mnemonic		AJ (Acceleration Type)
Mnemonic	Hi word	0x20 0x20
	Lo word	0x54 0x41
Parameter data length		2 bytes
	ASCII	= 1
	Hex	3D 31

4.4.17 Read/set backlash enable

Read or set the enabled/disabled state of the backlash compensation feature.

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc	
MCode mnemonic		BE (Backlash Enable)	
Mnemonic	Hi word	0x20 0x20	
	Lo word	0x45 0x42	
Parameter data length		2 bytes	
	ASCI	=	1
	Hex	3D	31

4.4.18 Read/set backlash amount

Read or set the backlash amount

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc						
MCode mnemonic		BL (Backlash Amount)						
Mnemonic	Hi word	0x20 0x20						
	Lo word	0x4C 0x42						
Parameter data length		up to 11 bytes						
	ASCI	=	2	5	6	0	0	0
	Hex	3D	32	35	36	30	30	30

4.4.19 Read/set backlash mode

Read or set the backlash mode to mathematical or mechanical

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc	
MCode mnemonic		BM (Backlash Mode)	
Mnemonic	Hi word	0x20 0x20	
	Lo word	0x4C 0x42	
Parameter data length		2 bytes	
	ASCI	=	1
	Hex	3D	31

4.4.20 Read/set deceleration jerk

Read or set the deceleration jerk for S-curve acceleration types

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc			
MCode mnemonic		DJ (Deceleration Jerk)			
Mnemonic	Hi word	0x20 0x20			
	Lo word	0x4A 0x44			
Parameter data length		up to 4 bytes			
	ASCII	=	1	2	8
	Hex	3D	31	32	38

4.4.21 Read/set deceleration type

Read or set the deceleration type for S-curve acceleration types

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc			
MCode mnemonic		DT (Deceleration Type)			
Mnemonic	Hi word	0x20 0x20			
	Lo word	0x54 0x44			
Parameter data length		2 bytes			
	ASCII	=	1		
	Hex	3D	31		

4.4.22 Read/set index offset

Read or set the offset from the index mark for Homing to Index Offset.

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc					
MCode mnemonic		DJ (Deceleration Jerk)					
Mnemonic	Hi word	0x20 0x20					
	Lo word	0x53 0x46					
Parameter data length		up to 6 bytes					
	ASCII	=	1	0	2	4	6
	Hex	3D	31	30	32	34	36

4.4.23 Home to index offset

Home to index offset command

Function		66 (0x42) Write Mfg Spc	
MCode mnemonic		HF (Home to Index Offset)	
Mnemonic	Hi word	0x20 0x20	
	Lo word	0x46 0x48	
Parameter data length		2 bytes	
	ASCII	=	1
	Hex	3D	31

4.4.24 hMT actual velocity

Returns the actual velocity of the axis when hMT is enable (closed loop LMD Models only)

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc					
MCode mnemonic		AV (hMT Actual Velocity)					
Mnemonic	Hi word	0x20 0x20					
	Lo word	0x56 0x41					
Parameter data length		up to 11 bytes					
	ASCII	7	8	6	0	0	0
	Hex	37	38	36	30	30	30

4.4.25 Following mode enable

Sets the enable/disable state for following mode.

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc			
MCode mnemonic		FL (Following Mode)			
Mnemonic	Hi word	0x20 0x20			
	Lo word	0x4C 0x46			
Parameter data length		2 bytes			
	ASCII	=	1		
	Hex	3D	31		

4.4.26 Software limits

Sets the direction, position and enabled state for software limit switches.

Function		65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc					
MCode mnemonic		LS (Software Limits)					
Mnemonic	Hi word	0x20 0x20					
	Lo word	0x53 0x4C					
Parameter data length		up to 16 bytes					
	ASCII	1			<±position>		1
	Hex	3D	31	2C	<±position>	, 2C	31

4.4.27 Upgrade

Place device in upgrade mode

Function		66 (0x42) Write Mfg Spc							
MCode mnemonic		UG (Upgrade)							
Mnemonic	Hi word	0x20 0x20							
	Lo word	0x47 0x55							
Parameter data length		2 bytes							
	ASCI	32	2	9	5	6	1	0	2
	Hex	20	32	39	35	36	31	30	32

5 Register map

NOTE: Registers highlighted in orange indicate function only available on closed loop models.

Function	Address	Bytes	Description	Range	Default	MCode
Acceleration	0x0000 - 0x0001	4	Sets the acceleration rate in steps per second ² .	91 to 1525878997	1000000	A
Reserved	0x0002-3	—	Reserved	—	—	—
Busy	0x0004	1	MCode program executing	—	—	BY
Counter 1	0x0005 - 0x0006	4	Variable contains the count of clock pulses generated by the device.	-2147483648 to +2147483647	0	C1
Counter 2	0x0007 - 0x0008	4	Variable contains the count of encoder counts read by the device. (Closed loop only)	-2147483648 to +2147483647	0	C2
Software reset enable	0x0009	1	Flag configures the device to respond (1) or not respond (0) to a CTRL+C software reset.	0/1	1	CE
Reserved	0x000A-D	—	Reserved	—	—	—
Clock width	0x000E	1	Sets the pulse width for the trip output	0 - 255	10 (500nS)	CW
Input 1 debounce	0x000F	1	Sets digital filtering in milliseconds. Input must be stable for the set time before state change is detected.	0 – 255	0	D1
Input 2 debounce	0x0010					D2
Input 3 debounce	0x0011					D3
Input 4 debounce	0x0012					D4
Analog input filter	0x0013	1	Filter does continuous average by computing: $((X-1)/X) \times \text{current reading} + (1/X)$ If $X = 10$, then: $((\text{current averaged value} \times 9)/10) + (\text{new reading} / 10) == \text{NEW current averaged value}$.	0 – 255	0	D5
Reserved	0x0014-17	—	Reserved	—	—	—
Deceleration	0x0018 - 0x0019	4	Sets deceleration rate in steps per second ² .	91 – 1525878997	1000000	D
Deadband ¹	0x001A	2	Encoder deadband (Closed loop only)	0 to ±65000	10	DB
Decrement variable	0x001B	1	instruction will decrement the specified variable by one.	—	—	DC
Drive enable	0x001C	1	Flag enables (1) or disables (0) the drive portion of the device.	0/1	1	DE
Reserved	0x001D	—	Reserved	—	—	—
Encode enable	0x001E	1	Enable encoder functions (Closed loop only)	0/1	0	EE
Error flag	0x001F	1	Flag indicates whether an error condition exists (1) or not (0).	0/1	0	EF
Reserved	0x0020	—	Reserved	—	—	—
Error	0x0021	2	Variable holds the error code of the last error. must be read or set to 0 to clear.	—	0	ER
Reserved	0x0022	—	Reserved	—	—	—
Filter capture	0x0024	1	Sets the digital filtering to be applied to Input 1 when configured as a Capture input	0 to 9	0	FC
Reserved	0x0025-28	—	Reserved	—	—	—
Holding current	0x0029	1	Sets the motor holding current in percent (%)	0 to 100	5	HC
Home to Index	0x002A	1	Home to i encoder index mark mode	1 to 4	—	HI

Function	Address	Bytes	Description	Range	Default	MCode
Homing mode	0x002B	1	Sets the behavior of the axis for homing routines: Mode=1 - Slew – at VM, creep + at VI Mode=2 - Slew – at VM, creep – at VI Mode=3 - Slew + at VM, creep – at VI. Mode=4 - Slew + at VM, creep + at VI	1 – 4		HM
Hold current delay time	0x002C	2	Set the time in milliseconds between the cessation of motion and shift to holding current percent. Total time is represented by the sum of 0x002C+0x0049 (motor settling delay time. The sum cannot be more than 65535 msec.	0 (no delay) or 2 – 65535	500	HT
Read input 1	0x002D	1	Read the logic state of the specified input.	0/1	—	I1
Read input 2	0x002E					I2
Read input 3	0x002F					I3
Read input 4	0x0030					I4
Read analog input	0x0031		Read the value of the analog input in counts.	0 – 1023	—	I5
Read index mark ¹	0.0032	1	This variable will read the on/off state of the Encoder Index Mark (Closed loop only)	0/1	—	I6
Reserved	0x0033-36	—	Reserved	—	—	—
Increment variable	0x0037	1	Increments the specified variable by one.	—	—	IC
Reserved	0x0038-3A	—	Reserved	—	—	—
Read all inputs as BCD	0x003B	1	Reads the logic states of inputs 1-4 and returns them as a decimal value. Input 1 will represent the LSb..	0 – 15	—	IN
Initialize parameters	0x003C	1	Reset all parameters to initial values	—	—	IP
Reserved	0x003D-E	—	Reserved	—	—	—
Jog enable	0x003F	1	Enables (1)/disables(0) jog functions when inputs are configured as Jog+ and Jog –.	0/1	0	JE
Reserved	0x0040-41	—	Reserved	—	—	—
Limit stop mode	0x0042	1	Sets the behavior of the axis upon reaching a limit switch. Mode=1 – Normal limit function with decel ramp. Mode=2 – Stops motion with decel ramp, no homing. Mode=3 – Stops motion with decel ramp, stops program. Mode=4 – Normal limit function, no decel. Mode=5 – Stops motion, no decel, no homing. Mode=6 – Stops motion, stops program, no decel.	1 – 6	1	LM
Move to absolute position	0x0043 - 0x0044	4	Point-to-point move to a ± absolute position.	—	—	MA
Moving to position	0x0045	1	Indicates that the axis is moving (1) to an absolute or relative position or stopped (0).	0/1	0	MP
Move to relative position	0x0046 - 0x0047	4	Point-to-point move to a ± position relative distance from current position.	—	—	MR

Function	Address	Bytes	Description	Range	Default	MCode																																																							
Microstep resolution	0x0048	1	Set the microstep resolution in microsteps per motor full step.	See table	256	MS																																																							
<table><tr><td colspan="11">Available Microsteps Per Revolution</td></tr><tr><td>0x0048=</td><td>1</td><td>2</td><td>4</td><td>5</td><td>8</td><td>10</td><td>16</td><td>25</td><td>32</td><td>50</td></tr><tr><td>steps/rev</td><td>200</td><td>400</td><td>800</td><td>1000</td><td>1600</td><td>2000</td><td>3200</td><td>5000</td><td>6400</td><td>10000</td></tr><tr><td>0x0048=</td><td>64</td><td>100</td><td>125</td><td>128</td><td>200</td><td>250</td><td>256</td><td>180</td><td>108</td><td>127</td></tr><tr><td>steps/rev</td><td>12800</td><td>20000</td><td>25000</td><td>25600</td><td>40000</td><td>50000</td><td>51200</td><td>36000¹</td><td>21600²</td><td>25400³</td></tr></table> 1=0.01 deg/μstep 2=1 arc minute/μstep 3=0.001 mm/μstep							Available Microsteps Per Revolution											0x0048=	1	2	4	5	8	10	16	25	32	50	steps/rev	200	400	800	1000	1600	2000	3200	5000	6400	10000	0x0048=	64	100	125	128	200	250	256	180	108	127	steps/rev	12800	20000	25000	25600	40000	50000	51200	36000 ¹	21600 ²	25400 ³
Available Microsteps Per Revolution																																																													
0x0048=	1	2	4	5	8	10	16	25	32	50																																																			
steps/rev	200	400	800	1000	1600	2000	3200	5000	6400	10000																																																			
0x0048=	64	100	125	128	200	250	256	180	108	127																																																			
steps/rev	12800	20000	25000	25600	40000	50000	51200	36000 ¹	21600 ²	25400 ³																																																			
Motor settling delay time	0x0049	2	Specifies the motor settling delay time in milliseconds. This allows the motor to settle following a move. This variable is added to 0x002C to determine the total time before shifting to holding current. The sum cannot be more than 65535 msec.	0 – 65000	0	MT																																																							
Moving	0x004A	1	Indicates whether the axis is in motion (1) or stationary (0).	0/1	0	MV																																																							
Write output 1	0x004B	1	Write (set) the logic state of the specified output.	0/1	—	O1																																																							
Write output 2	0x004C					O2																																																							
Write output 3	0x004D					O3																																																							
Output fault	0x004E	1	Output fault flag indicates a faulted state of an output when true.	0/1	0	OF																																																							
Reserved	0x004F-55	—	Reserved	—	—	—																																																							
Set outputs 1 - 4 as a group	0x0056	1	Set outputs 1-4 as one 4 bit binary value. The value is entered in decimal, with a range of 0-15 in binary where output 1 will be the LSB	0 – 15	—	OT																																																							
Position counter	0x0057 - 0x0058	4	Sets or reads the axis ± position in motor steps. The value of the register will be used as the reference point for absolute and relative moves.	-2147483648 – +2147483647	0	P																																																							
Position capture at trip	0x0059 - 0x005A	4	Captures axis position during a trip event. Activation will occur upon any trip function EXCEPT a position trip.	—	—	PC																																																							
Reserved	0x005B	—	Reserved	—	—	—																																																							
Position maintenance	0x005C	1	Enables (1) or disables (0) position maintenance functions (Closed loop only)	0/1	0	PM																																																							
Reserved	0x005D-5E	—	Reserved	—	—	—																																																							
User register 1	0x005F - 0x0060	4	registers may contain up to 11 digits including the sign and may be used to store and retrieve data.	32 bit	—	R1																																																							
User register 2	0x0061 - 0x0062					R2																																																							
User register 3	0x0063 - 0x0064					R3																																																							
User register 4	0x0065 - 0x0066					R4																																																							
Run current	0x0067	1	Sets the motor run current in percent (%).	1 to 100	25	RC																																																							
Reserved	0x0068-75	—	Reserved	—	—	—																																																							

Function	Address	Bytes	Description	Range	Default	MCode
Save	0x0076	1	Saves variables and flags in working memory to NVM.		—	S
Stall factor	0x0077	2	Difference between commanded position and encoder counts at which a stall is indicated (Closed loop only).	0 to 65000	15	SF
Slew axis	0x0078 - 0x0079	4	Slews the axis at velocity in steps/second in the specified $\pm$ direction, Slew velocity is independent of 0x008B (maximum velocity).	± 5000000	—	SL
Stall mode	0x007A	1	Stall detection mode determines the response to a stall detect, either motion stops (0) or attempts to continue (1) (Closed loop only).	0/1	0	SM
Stall flag	0x007B	1	indicates a motor stall (1) or not stalled (0) (Closed loop only).	0/1	0	ST
Reserved	0x007C	—	Reserved	—	—	—
Trip enable	0x007D	1	Enables/re-enables trip functions as specified by the table below. Multiple trips may be specified by adding the trip definitions i.e. 0x007D=10 will allow trip on position (2) and trip on time (8). Trips are set up using manufacturer function codes 65 (0x41) and 66 (0x42) Trip enable definitions: 0 – Trip functions disabled. 1 – Reserved 2 – Reserved 4 – Reserved 8 – Reserved 16 – Trip on relative position 32 – Reserved	0 – 43	0	TE
Reserved	0x007E-84	—	Reserved	—	—	—
Read axis velocity	0x0085 - 0x0086	4	Reads the current velocity in motor steps per second. NOTE: If hMTechnology circuitry is in make-up mode, 0x0085-86 will not return an accurate value. When the hMTechnology product is in torque control mode 0x0085-86 will return a zero (0). Read only variable.	—	—	V
Reserved	0x0087	—	Reserved	—	—	—
Velocity is changing	0x0088	1	Axis velocity is changing (1) or constant (0). Read only status flag.	0/1	0	VC
Set initial velocity	0x0089 - 0x008A	4	Set the initial velocity of the axis in motor steps per second.	1 to max. velocity – 1	1000	VI
Set maximum velocity	0x008B - 0x008C	4	Set the maximum velocity of the axis in motor steps per second.	Initial velocity +1 to 2560000	768000	VM
Warning temp	0x008D	—	Sets the temperature at which a warning error is asserted/	0 to 84	80	WT

5.1 hMTechnology specific registers (Closed loop only)

Function	Address	Bytes	Description	Range	Default	MCode
Set hMTechnology mode	0x008E	1	Sets the hMTechnology operational behavior to one of four modes, detailed below: 0 hMTechnology circuitry disabled. 1 Fixed current mode. Current is set by the run and hold current commands, Speed is set by the system speed command. 2 Variable current mode. Current will vary as needed to position the load with the maximum current set by the run current command. 3 Torque mode, torque and speed will vary as needed to move/ position the load with the maximum torque % and speed as specified by the torque and torque-speed commands.	0 – 3	2	AS
Read hMTechnology status	0x008F	1	Read only status flag will return the conditions listed below. If multiple conditions exist the result is additive. i.e. At zero (64) and Calibration complete (128) AF=192 1 – Rotor lead limit reached. 2 – Rotor lag limit reached. 4 – Maximum lead/lag limit reached. 8 – Locked rotor. 16 – hMTechnology mode is active. 32 – Hardware fault condition exists. 64 – At zero (0). 128 – Calibration s complete.	1 – 255	—	AF
Reserved	0x0090	—	—	—	—	—

Function	Address	Bytes	Description	Range	Default	MCode
Set control bounds	0x0091	1	The control bounds are limits which configure the hMTechnology circuitry for best speed or torque performance. For torque mode operation the control bounds are preset for best torque performance. 0 – 1.1 full steps (best torque performance). 1 – 1.3 full steps (best overall performance). 2 – 1.5 full steps (best overall performance). 3 – 1.7 full steps (best speed performance).	0 – 3	1	CB
Reserved	0x0092	—	—	—	—	—
Clear locked rotor	0x0093	1	Will clear a locked rotor fault, re-enable the output bridge and initiate a timed calibration.	—	—	CF
Reserved	0x0094	—	—	—	—	—
Lead limits	0x0095 – 0x0096	4	Sets the rotor lead limit in motor steps	0 – 2147483647	102400	LD
Lag limits	0x0097 – 0x0098	4	Sets the rotor lag limit in motor steps	0 – 2147483647	102400	LG
Position lead/lag	0x0099 – 0x009A	4	Represent the number of counts that the rotor leads or lags the stator. A positive value indicates position lag. A negative value indicates position lead	–2147483647 to +2147483647	—	LL
Locked rotor	0x009B	1	Indicates the state of the rotor as locked (1) or unlocked (0).	0/1	0	LR
Locked rotor timeout	0x009C – 0x009D	2	Sets the time in milliseconds in which the output bridge will disable after a locked rotor condition is detected.	2 – 65535	2000	LT
Make up frequency	0x009E – 0x009F	4	Sets the frequency in Hz at which missed steps are re-inserted into the move profile if make up mode = 1.	306 – 2560000	768000	MF
Make up	0x00A0	1	Sets the mode for make up steps. 0 = Off 1 = Make up steps at make up freq. (0x009E) 2 = Make up steps at system speed	0 – 2	0	MU
Start configuration test	0x00A1	1	Start configuration test process	—	—	SC
Reserved	0x00A2	—	Reserved	—	—	—
Set torque speed	0x00A3 – 0x00A4	—	Determines the system speed for torque mode (AS=3) The device will perform the following calculation based upon the value of TS: Oscillator frequency = 10 MHz / (TS+2)	0 – 255	—	—
Torque direction	0x00A5	1	Sets the torque direction plus (1 – CW) or minus (0 – CCW) as seen facing the motor shaft.	0 – 1	1	TD
Set torque	0x00A6	1	Sets the motor torque in percent for torque mode operation.	1 – 100	25	TQ
hMT Velocity Filter)	0x00A7	—	VF takes a value of 0 to 1000. It can be defined as 0 = no filtering and 1000 = most filtering. Because the Torque Velocity is computed and the encoder is sampled every mSec there can be fluctuation in the result. The filtering compensates for this fluctuation.	0 – 1000	0	TS

5.2 User variable registers

The user variable registers are ONLY used to interact with MCode programs being executed using the Manufacturer Specific function code. They cannot be used for MODBUS/TCP standalone operation.

If using V1 – V8 to store or retrieve data, the variables must be declared within the MCode program using the VA (Create user variable) command.

Function	Address	Bytes	Description	Range	Default	MCode
V1	0x00A8 - 0x00A9	4	User variable 1	Variables may contain up to 11 digits including the sign and may be used to store and retrieve data.	—	V1
V2	0x00AA - 0x00AB	4	User variable 2		—	V2
V3	0x00AC - 0x00AD	4	User variable 3		—	V3
V4	0x00AE - 0x00AF	4	User variable 4		—	V4
V5	0x00B0 - 0x00B1	4	User variable 5		—	V5
V6	0x00B2 - 0x00B3	4	User variable 6		—	V6
V7	0x00B4 - 0x00B5	4	User variable 7		—	V7
V8	0x00B6 - 0x00B7	4	User variable 8		—	V8

6 TCP/IP Configuration Utility

The TCP/IP configuration Utility is used to configure and rest the functionality of LMD Ethernet units.

For installation and usage instructions see the LMD Software Suite Manual available online at: <https://novantaims.com/dloads/>

Warranty

For the latest warranty and product information, visit: <https://novantaims.com/warranty-and-disclaimer/>

Document Revision History

Document Number: LMD-MODBUS-REV-D		
Date	Revision	Changes
06/27/2013	LMD-MODBUS-REV-C	Initial Release
01/25/2014	V1.00, 01.2014	Updated changes to register map.
01/15/2014	V1.00, 08.2014	Corrected max velocity from 5 to 2.56 MHz.
08/04/2016	V1.10,04.2016	Updated to reflect firmware releases. New features added supporting the release of the MCode Operating System Version 6
02/05/2019	LMD-MODBUS-REV-C	Updated to show LMD absolute encoder products
02/25/2022	LMD-MODBUS-REV-D	Updated to Novanta Brand

Novanta IMS is a part of the Precision Motion Group within Novanta, a leading technology company that delivers innovation to medical and advanced industrial OEMS.

As standards, specifications, and designs may change, confirmation of the information given in this publication can be found in the product disclaimer and most recent product information, available online.

<https://novantaims.com/all-products/>

© 2022 Novanta IMS. All rights reserved.

Photos: Novanta IMS

Print: Novanta IMS

To provide feedback on Novanta IMS documentation, send an e-mail to:

documentation@imshome.com

Novanta IMS

370 North Main Street

Marlborough, CT 06447

Phone: (860) 295-6102

www.novantaims.com