



TETRA COMPACT-E 130


230 Vac TORQUE AND SPEED CHARTS .1




TETRA COMPACT-E 130 5A F1 2




TETRA COMPACT-E 130 5B L1 2



TETRA COMPACT-E 130 5C F1 2



TETRA COMPACT-E 130 5D F4 2




— Continuous torque
- - - Peak torque

SEE IT BEFORE IT HAPPENS

**MOTOR
POWER**
COMPANY



TETRA COMPACT-E 130

230 Vac TORQUE AND SPEED CHARTS .2





TETRA COMPACT-E 130 5E L1 2

TETRA COMPACT-E 130 5F L1 2



TETRA COMPACT-E 130 5G H1 2

TETRA COMPACT-E 130 5H F4 2




— Continuous torque
- - - Peak torque

SEE IT BEFORE IT HAPPENS


**MOTOR
POWER**
COMPANY

TETRA COMPACT-E 130


400 Vac TORQUE AND SPEED CHARTS .1




TETRA COMPACT-E 130 5A F1 4




TETRA COMPACT-E 130 5B L1 4



TETRA COMPACT-E 130 5C F1 4



TETRA COMPACT-E 130 5D F4 4




— Continuous torque
- - - Peak torque

SEE IT BEFORE IT HAPPENS


**MOTOR
POWER**
COMPANY

TETRA COMPACT-E 130


400 Vac TORQUE AND SPEED CHARTS .2




TETRA COMPACT-E 130 5E L1 4




TETRA COMPACT-E 130 5F L1 4



TETRA COMPACT-E 130 5G H1 4



TETRA COMPACT-E 130 5H F4 4



— Continuous torque
- - - Peak torque

SEE IT BEFORE IT HAPPENS

**MOTOR
POWER**
COMPANY